



725 Cesar Chavez, San Francisco, CA 94124
 P: (415) 642-6888 P:(800) 995-0573 F: (800) 962-2893
 www.pacificdoorcloser.com info@pacificdoorcloser.com

Wikk EXCEL MANUAL BALANCED HARDWARE CONCEALED HINGE TUBE

REF. LET.	REF. NO.	DESCRIPTION	PER UNIT
AE/LE		Top Hinge Pivot/Spring Bumper Assembly #	1
	AE	Top Hinge Tube Pivot Assembly	1
	LE	Spring Bumper Assembly	1
	103	12- 24 x 1/2 Ph. Fl. Hd. Machine Screw #	4
	187	5/8 O.D. x 4.5" Spring	1
BE		Excel Guide Tr & Ck Assembly * #	1
	103	12-24 x 1/2 Ph. Fl. Hd. Machine Screw #	4
	111	Check Arm Roller Assembly	1
	112	Roller Assembly Set Screw	1
	142	Door Check *	1
	189	Check Arm Mounting Screw #	1
	190	Spindle Extension	1
	191 S	Short Arm Guide Track Set *#	1
	191 W	Wide Arm Guide Track Set *#	1
	193	Track Assy. Mtg. Bracket	1
	194	12-24x3/4 Ph. Fl. Hd. Machine Screw #	2
	197 S	Short Check Arm * #	1
	197 W	Wide Check Arm * #	1
	CE		Excel Check Track Assembly
117		1/4- 20 x 1/2 Ph. Fl. Hd. Machine Screw	5
188		Check Track	1
GE2000		Excel Guide Roller Assembly	1
	42	Guide Roller	1
	95	Guide Roller Door Bracket	1
	126	1/4 - 20 x 3/4 Soc. Hd. Cap Screw	4
E		Top Door Pivot Assembly #	1
	8	Needle Bearing	1
	9	Radial Bearing	1
	19	Top Door Pivot #	1
	20	5/16 - 18 x 3/4 Socket Head Cap Screw	2
	73	5/16 Helical Lock washer	2
F NM		Bottom Door Pivot Assembly #	1
	10	Bottom Door Pivot Pin	1
	19	Bottom Door Pivot #	1
	20	5/16 - 18 x 3/4 Socket Head Cap Screw	2
	22NM	Bottom Door Pivot Shim, Non-Metal	1
	73	5/16 Helical Lock washer	2
G		Hinge Tube Assembly * #	1
	3	Hinge Tube (No Longer Available)	1
	76	Wedge	4
	123	Torsion Spring	1
	124	1/4 x 1 1/4 Roll Pin	1
	138 NUT	Hinge Tube Nut with Roll Pin	2
	140A	Torsion Spring Anchor	1

REF. LET.	REF. NO.	DESCRIPTION	PER UNIT
K NM		Bottom Arm Top Pivot Assembly	1
L		Bottom Arm Bottom Pivot Assembly	1
	29	Radial Bearing	1
	30	Needle Bearing	1
	31	Thrust Washer	2
	32	Needle Bearing	1
	134	Seal	1
	135	Hinge Shaft Pivot, Toothed	1
	145	Snap Ring	1
M		Bottom Arm Assembly * #	1
	1 S	Bottom Arm, Short (Cast) * #	1
	1 W	Bottom Arm, Wide (Cast) * #	1
	107	1/4 - 20 x 1/4 Soc. Set. Screw	1
	139 BOT	Socket Head Cap Screw	1
	REF K NM	Bottom Arm Top Pivot Assembly	1
REF L	Bottom Arm Bottom Pivot Assembly	1	
N		Top Arm Assembly * #	1
	2 S	Top Arm, Short (Cast) * #	1
	2 W	Top Arm, Wide (Cast) * #	1
	17	Top Arm Pivot Shaft	1
	29	Radial Bearing	1
	30	Needle Bearing	1
	47	3/8 - 16 x 5/8 Socket Set Screw Cup Pt.	1
	107	1/4 - 20 x 1/4 Soc. Set. Screw	1
	139 TOP	Socket Head Cap Screw	1
	O		Hinge Jamb Base Plate Assembly *
36-1		Bottom Hinge Pivot Shim .062"	2
36-2		Bottom Hinge Pivot Shim .031"	2
103		12-24 x 1/2 Ph. Fl. Hd. Mach. Screw #	3
131		Tension Adjuster *	1
132		Hinge Jamb Base Plate	1
152		Mounting Screw	2
194		12-24x3/4 Ph. Fl. Hd. Machine Screw #	4
AE/NS	alternate	Top Hinge Pivot Assembly	1
BED	optional	Excel Guide Track & Delay Check	1
FP	optional	Finish Plate Assembly * #	1
HO	optional	Hold Open Assembly #	1
N FC	optional	Flush Ceiling Top Arm Prep	1
TE	optional	Threshold Prep'd Exposed	1

* = Handed Part
 # = Finish Dependent

Parts in bold borders are sold as assemblies only.

Order parts by Reference Number or Letter.