

PARTS LIST



WIKK EXCEL AUTOMATIC BALANCED HARDWARE EXPOSED HINGE TUBE

REF. LET.	REF. NO.	DESCRIPTION	PER UNIT	
AE/LE		Top Hinge Pivot/Spring Bumper Assembly #	1	
	LE	LE Spring Bumper Assembly	1	
	187	1M130 5/8 O.D. x 4.5" Spring	1	
	AE	AE Top Hinge Tube Pivot Assembly	1	
	103	1M439 12- 24 x 1/2 Ph. Fl. Hd. Machine Screw #	4	
BA		Excel Guide Tr & Ck Assembly * #	1	
	103	1M439 12-24 x 1/2 Ph. Fl. Hd. Machine Screw #	4	
	111	1M347 Roller Assembly	1	
	112	Roller Assembly Locking Screw	1	
	H102C	Control Handicap Control with Close Boost	1	
	H102 LO	Power Transformer & Electrical Box Assembly	1	
	H102C	Harness 14 Pin Harness	1	
	142 AUTO	LH Door Check *	1	
	142 AUTO	RH Door Check *	1	
	189	1M450 Check Arm Mounting Screw	1	
	190	Spindle Extension	1	
	191	8M019 Sh Arm Guide Track Set * #	1	
	191	8M020 W Arm Guide Track Set * #	1	
	193	1M115A Track Assy. Mtg. Bracket	1	
	194	1M438 12-24x3/4 Ph. Fl. Hd. Machine Screw #	2	
	197	2010-35 Check Arm Sh. Arm Door * #	1	
	197	4010SEL Check Arm W Arm Door * #	1	
	CE		Excel Check Track Assembly	1
		117	1M435 1/4- 20 x 1/2 Ph. Fl. Hd. Machine Screw	5
188		1M129 Check Track	1	
GE2000		Excel Guide Roller Assembly	1	
	42	23 Guide Roller	1	
	95	1M175 Guide Roller Door Bracket	1	
	126	1M436 1/4 - 20 x 3/4 Soc. Hd. Cap Screw	4	
E		Top Door Pivot Assembly #	1	
	8	54 Needle Bearing	1	
	9	52 Radial Bearing	1	
	19	1M168 Top Door Pivot #	1	
	20	1M440 5/16 - 18 x 3/4 Socket Head Cap Screw	2	
	73	1M432 5/16 Helical Lockwasher	2	
F NM		Bottom Door Pivot Assembly #	1	
	10	Bottom Door Pivot Pin	1	
	19	1M168 Bottom Door Pivot #	1	
	20	1M440 5/16 - 18 x 3/4 Socket Head Cap Screw	2	
	22 NM	Bottom Door Pivot Shim, Non-Metal	1	
	73	1M432 5/16 Helical Lockwasher	2	
G		Hinge Tube Assembly * #	1	
	3	21 Hinge Tube	1	
	74	1M003 Hinge Tube Cover #	1	
	76	1M171 Wedge	4	
	78	1M005 Pile Weather Stripping	2	
	79	1M006 Spacer	2	
	123	1M025 Torsion Spring	1	
	124	1M465 1/4 x 1 3/4 Roll Pin	1	
	138 NUT	1M855 Hinge Tube Nut with Roll Pin	2	
	140A	1M172A Torsion Spring Anchor	1	

REF. LET.	REF. NO.	DESCRIPTION	PER UNIT
K NM		Bottom Arm Top Pivot Assembly	1
L		Bottom Arm Bottom Pivot Assembly	1
	29	51 Radial Bearing	1
	30	53 Needle Bearing	1
	31	58 Thrust Washer	2
	32	56A Needle Bearing	1
	134	1M087 Seal	1
	141	1M033 Hinge Shaft Pivot, Toothed	1
	145	1M081 Snap Ring	1
M		Bottom Arm Assembly * #	1
	1	4M218 Bottom Arm, Left Hand Short (Cast) * #	
	1	4M219 Bottom Arm, Right Hand Short (Cast) * #	
	1	4M214 Bottom Arm, Left Hand Wide (Cast) * #	
	1	4M215 Bottom Arm, Right Hand Wide (Cast) * #	
	107	1M434 1/4 - 20 x 1/4 Soc. Set. Screw	1
	139 BOT	1M080 Socket Head Cap Screw	1
	REF K NM		Bottom Arm Top Pivot Assembly
REF L		Bottom Arm Bottom Pivot Assembly	1
N		Top Arm Assembly * #	1
	107	1M434 1/4 - 20 x 1/4 Soc. Set. Screw	1
	2	4M216 Top Arm, Left Hand Short (Cast) * #	
	2	4M217 Top Arm, Right Hand Short (Cast) * #	
	2	4M212 Top Arm, Left Hand Wide (Cast) * #	
	2	4M213 Top Arm, Right Hand Wide (Cast) * #	
	139 TOP	1M080 Socket Head Cap Screw	1
	47	1M424 3/8 - 16 x 5/8 Socket Set Screw Cup Pt.	1
	17	1M167 Top Arm Pivot Shaft	1
	29	51 Radial Bearing	1
	30	53 Needle Bearing	1
OE		Hinge Jamb Base Plate Assembly *	1
	36-1	93-1 Bottom Hinge Pivot Shim .062	2
	36-2	93-2 Bottom Hinge Pivot Shim .031	2
	129	1M096 Offset Tension Adjusted *	1
	152	1M443 Mounting Screw	6
	128	1M034 Bottom Hinge Tube Pivot	1
TE	optional	Threshold Prep'd Exposed	1
HO	optional	Hold Open Assembly #	1
FP	optional	1M017 Finish Plate Assembly * #	1
N FC	optional	Flush Ceiling Top Arm Prep	1

* = Handed Part
= Finish Dependent

Parts in bold borders are sold as assemblies only.

Order parts by Reference Number or Letter.